

ShiftCam

Packaging Inserts - SnapLight Quick Start Guide

ShiftCam SnapLight

Quick Start Guide

Guide de démarrage rapide

Guía rápida de inicio

Attach SnapLight / Fixez SnapLight

Acople SnapLight / SnapLight befestigen

iPhone 12 series or later, or with a MagSafe case /
Série iPhone 12 ou ultérieur, ou avec un étui MagSafe
iPhone serie 12 o posterior, o con una funda MagSafe /
Für iPhone 12 und neuere Modelle oder mit einem
MagSafe Case

For other phones / Autres Smartphones

Otros teléfonos / andere Smartphones

Magnetic Sticker included /
Autocollant magnétique inclus
Pegatina magnética incluida /
Necesario adhesivo magnetico

1

2

Front

Adjust Brightness Level

Ajuster le niveau de luminosité

Ajuste del nivel de luminosidad /
Helligkeit einstellen

Power Button

Bouton d'alimentation

Botón de alimentación /
Power-Taste

Long press to turn on / off.
Appuyez longuement pour
allumer / éteindre.
Pulsación prolongada para
encender/apagar

Button Press

Appuyez sur le bouton

Pulsar el botón

				Times Fois Nº de veces
1	2	3	4	

Hints and tips
Trucs et astuces
Consejos y recomendaciones /
Hinweise & Tipps

Back

ShiftCam SnapLight

Quick Start Guide

Guide de démarrage rapide

Guía rápida de inicio


Attach SnapLight / Fixez SnapLight

Acople SnapLight / SnapLight befestigen

iPhone 12 series or later, or with a MagSafe case /
Série iPhone 12 ou ultérieur, ou avec un étui MagSafe

iPhone serie 12 o posterior, o con una funda MagSafe /

Für iPhone 12 und neuere Modelle oder mit einem
MagSafe Case





For other phones / Autres Smartphones

Otros teléfonos / andere Smartphones

Magnetic Sticker included /
Autocollant magnétique inclus

Pegatina magnética incluida /

Necessario adesivo magnetico



Adjust Brightness Level

Ajuster le niveau de luminosité

Ajuste del nivel de luminosidad / Helligkeit einstellen



Power Button
Bouton d'alimentation
Botón de alimentación /
Power-Taste

Long press to turn on / off.
Appuyez longuement pour
allumer / éteindre.
Pulsación prolongada para
encender/apagar

Button Press
Appuyez sur le bouton
Pulsar el botón

				Times Fois N° de veces
1	2	3	4	



  **Hints and tips** →
Trucs et astuces
  **Consejos y recomendaciones /
Hinweise & Tipps**