

chipolo

www.chipolo.net/instructions

english • français • deutsch • italiano • español • slovenščina • nederlands
svenska • suomi • norsk • РУССКИЙ ЯЗЫК • 日本語 • português • ...

[chipolo.net](http://www.chipolo.net) • [#chipolo](https://twitter.com/chipolo) • [@chipolo_tm](https://www.instagram.com/chipolo_tm) • [f chipolotm](https://www.facebook.com/chipolotm) • [ChipoloTM](https://www.tiktok.com/@chipolotm)

Chipolo CARD Spot

USER MANUAL

CHIPOLO CARD SPOT

Chipolo CARD Spot is an item finder that helps you locate your personal items using the Apple Find My app on your iPhone, iPad, iPod touch, or Mac, and the Find Items app on Apple Watch.

LET'S GET STARTED

- 1 Open the Find My app on your iPhone or iPad, tap + and "Add Other Item (+)".
- 2 While the Find My app is searching, press the button on your Chipolo once and you will hear a beep.
- 3 After setup, you can locate your Chipolo CARD Spot in the Find My app on your iPhone, iPad, iPod touch, or Mac, and the Find Items app on Apple Watch.

BASIC FEATURES

Spot is a special edition of Chipolo CARD that works exclusively with the Apple Find My network. The Find My network provides an easy, secure way to locate your personal items using the Find My app on your iPhone, iPad, iPod touch or Mac. Simply pair your Chipolo CARD Spot with the Find My app to view it right alongside your Apple devices. If a personal item connected to Chipolo CARD Spot ever goes missing, use the Find My app to locate it on a map and play a sound

if the item is nearby. You can also put your Chipolo CARD Spot in Lost Mode to display a message and a phone number or email address to anyone who might find it.

NEED HELP?

Visit our support pages at www.chipolo.net/support or contact our customer support at support@chipolo.net

BATTERY

2-year non-replaceable battery (lasts at least 2 years, renewal options available - www.chipolo.net/renewal-spot).
Battery type - CP124653

RENEWAL PROGRAM

You can replace your Chipolo CARD Spot using the discounted renewal program.

Register the product right after activation as you will receive your renewal discount two years after the registration.

More info at www.chipolo.net/renewal-spot

TECHNICAL SPECIFICATIONS

For more information visit www.chipolo.net/support

FACTORY RESET

How to do a factory reset:

1. Press the button on your CARD Spot for 30 seconds.
2. CARD Spot will begin to beep in 1-second intervals.
3. Release the button right after you hear the 5th beep.
4. After a successful factory reset you will hear a confirmation sound.

DISABLE AND RE-ENABLE CARD SPOT

How to disable CARD Spot:

1. Press the button on your CARD Spot for 30 seconds.
2. CARD Spot will begin to beep in 1-second intervals.
3. Release the button right after you hear the 10th beep.
4. When the CARD Spot is disabled you will hear a confirmation sound.

How to re-enable the finder:

1. Press the button on your CARD Spot to re-enable it.
2. When the CARD Spot is re-enabled you will hear a confirmation sound.

REQUIREMENTS

To use the Find My app to locate this item, the latest version of iOS, iPadOS, watchOS or macOS is recommended.

PRIVACY

The Apple Find My network uses advanced encryption to ensure that no one else, not even Apple or Chipolo can view the location of your Chipolo CARD Spot.

SPECIFICATIONS

Range: up to 60 m (200 ft) - line of sight
Temperature range: -15 °C to +50 °C (5 °F to 122 °F)
Modulation method: GFSK, Antenna power: < 1 mW
Operating frequency band: 2402-2480 MHz

WARNING

This product is not a toy or edible. Mobile device casings can interfere with signal strength and decrease Chipolo's visibility. Large metal parts near your mobile devices and your Chipolo can interfere with the Bluetooth signal. Caution! Lithium battery inside. Risk of explosion in case of incorrect use. Please do not expose the product to a direct heat source. Please do not expose the product to any

mechanical stress or impact. Do not attempt to disassemble your Chipolo. You run the risk of electric shock and voiding your warranty. Tips for the most efficient usage can be found at www.chipolo.net/faqs

WARRANTY

2 years

DECLARATION OF CONFORMITY

This product is compliant with CE and FCC directives. This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.
- The relevant Declaration of Conformity is available at www.chipolo.net/regulatory. Any changes or modifications not expressly approved by the party responsible for compliance, may void the authorization to operate this equipment. This device complies with the RF exposure SAR test exclusion requirements for portable devices if a minimum separation distance of 5 mm is kept. However, the device shall be used in such a manner that the potential for human contact during normal operation is minimized.

WEEE DIRECTIVE & PRODUCT DISPOSAL

At the end of its service life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for recycling of electrical and electronic equipment or returned to the supplier for disposal.

LEGAL

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, iPad, iPhone, iPod touch, Mac, iPadOS, macOS, watchOS and Find My are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. & other countries and is used under license.