








Device and Browser Compatibility

For Teachers Access your Ozobot Classroom dashboard from:

 DEVICE	 BROWSER	 Evo Educator Entry Kit	 Evo Classroom Kit
Chrome OS	Chrome 56+	✓	✓
Apple Mac OS X 10.10+	Chrome 56+	✓	✓
Apple iOS Tablets		✗	Coming Soon
Android 6.0+ Tablets	Chrome 56+	✗	Coming Soon
Windows 7, 8.1, or 10	Chrome 70+	✗	TBD

For Students (when using OzoBlockly)

 DEVICE	 Evo Educator Entry Kit	 Evo Classroom Kit
Chromebook		Coming Soon
Apple computer		TBD
Apple iOS tablets		TBD
Android tablets		TBD
Windows computer		✗

Ozobot Bit users: Bit is not Bluetooth-enabled or fully Ozobot Classroom compatible. You can still create an account to access teacher training, free K-12 lessons, and more.